



FLEXSTONE
LUXURIOUS BATH SURROUNDS

Remodel Trim Install Instructions

Read all instructions before starting

For missing items do not return to store.

Please call 877-941-3662

(Monday – Friday 8:00 a.m. – 5:00 p.m MT)

RECOMMENDED: Visit <http://FlexstoneProducts.com/installation> to access a walk-through video and other useful installation information.

Remodel Trim Instructions

Remodel Trim

FLXRTK3296



Installation of Remodel Trim

1. Remodel Trim allows FlexStone to be used over existing tile. Tile should be in good shape, clean and dry, and wall surfaces should be flat (i.e. remove any accessories that would interfere with the FlexStone panels). The Remodel Trim will need to be cut to proper length and mitered according to the FlexStone Bath Kit being installed.

2. The return lip of the trim (the one without the finished edge) is oversized to fit almost any bathroom tile thickness, and should be cut to size depending on your tile thickness. Size the lip to cover the existing tile, plus the FlexStone wall panel, plus approx. 1/4" of space for adhesive (adhesive between tile and FlexStone wall panel, and adhesive between panel and trim molding). Use a table saw, if available, to easily rip the trim lip to size, or a straight edge and utility knife.

3. Follow instructions for installation of your particular FlexStone Bath kit, using the Remodel Trims in place of standard trims.



Cut lip to size depending on tile thickness



FLEXSTONE
LUXURIOUS BATH SURROUNDS