



FLEXSTONE
LUXURIOUS BATH SURROUNDS

Seam Strip Trim Install Instructions

Read all instructions before starting

For missing items do not return to store.

Please call 877-941-3662

(Monday – Friday 8:00 a.m. – 5:00 p.m MT)

RECOMMENDED: Visit <http://FlexstoneProducts.com/installation> to access a walk-through video and other useful installation information.

Seam Strip Trim Instructions

Seam Strip Trim

FLXDG396



Installation of Seam Strip Trim

1. Seam Strip Trims are used to cover joints between two wall panels, or to divide the back wall panel of a FlexStone Bath Kit, which makes installation much easier. The Seam Strip is 3" wide, and can cover gaps between panels of up to 2-1/2".
2. Measure from the tub or shower base to the bottom of the horizontal edge trim of the bath kit. Cut the Seam Strip Trim to this length.
3. Peel away protective masking from the trim, apply construction adhesive to the back of the trim, keeping the adhesive away from the edges (to avoid adhesive squeezing out the edges.) If the gap between the panels is larger than approx 1/4", fill it with adhesive as well.
4. Secure trim in place, and hold with painters' tape while the adhesive cures.
5. Seal all edge joints with 100% silicone, as with the rest of the surround.

